

Hunter Innovations, Ltd.

Installation Instructions

If you choose to install your Lamp Post or Birdfeeder Post, follow the instructions below for a quality installation.

Tools/Materials Needed for Installation

- Post Hole diggers or Auger
- Shovel
- Level
- Bag of Cement
- Water
- Stick or other stirring device for the cement
- Sand (if you have very rocky soil)

*Procedure for Installation***

1. Dig a hole that is approximately 9 inches in diameter and 18 inches deep.
2. Pour the hole approximately half full of water.
3. Put in dirt/sand, which you had left from digging, until it almost fills the water. Try to avoid any medium and large size rocks getting into the hole.
4. Pour in approximately 1 gallon of cement.
5. Stir and adjust levels of water, dirt, and cement to get a firm but not hard mixture. The mixture should fill the hole with the exception of 2-3 inches at the top.
6. Remove the stirring device and push the post into the hole until it touches the bottom of the hole.
7. Use the remaining dirt/sand to fill and cover the hole.
8. Straighten the post up using the level and pack some of the loose dirt around the base of the post.
9. Clean up the remaining dirt/sand with the shovel.
10. Attach your fixture and enjoy.

** If you are not sure about where underground wires are; contact your local utility companies to locate the wires prior to digging. Also, make sure your electrician has run the wire for your Lamp Post and threaded it through the post prior to installation.

** Make sure all electrical service is performed by a licensed electrician.