

Window Garden Accent Installation on Masonry

1. Position the Window Garden Accent (WGA) where desired and hold intact.
2. Using a drill with a 3/16" wood/metal bit drill through the back panel of the WGA and mark the vertical mortar joint. (Note: a masonry bit can be used for this, but will not drill through the PVC as well as a wood/metal bit). Drill holes evenly spaced for four screw/shields per WGA.
3. Remove the WGA
4. Using a 3/16" masonry bit, drill a hole deep enough for the plastic shield provided.
5. Insert the enclosed shields into the bored holes. (one shield per hole)
6. Reposition the WGA aligning the holes over the shields
7. Insert the enclosed #8 x 1-1/2" screws and tighten with drill or screw driver.
8. Ensure the screw head is tight against the back panel of the WGA
9. Do not install above habitable space.
10. Ensure the flower pots have adequate drainage to dissipate excessive water-weight.

