

Window Garden Accent Installation on Siding

1. Position the Window Garden Accent (WGA) where desired and hold intact.
2. Using a drill with a 1/8" wood/metal bit, pre-drill 4 holes through the WGA and the siding equally spaced across back panel of the WGA. Position the WGA where the screw will contact the framing under the window as shown.
3. Using a drill, drive the enclosed 3" screws into the holes (one per hole).
4. Ensure the screw head is tight against the back panel of the WGA
5. Do not install above habital space.
6. Ensure the flower pots have adequate drainage to disapate excessive water-weight.

